


BBB B180 AV Instructions

Touch the handheld Crestron to turn on projector




Connect HDMI to your Laptop/Macbook

- (Use adapter if necessary)
- Unmute volume button on the bottom if you are playing sound



To use the Lectern/ Handheld microphone

- Press the mic unmute button on the bottom and press the button that is circled blue to unmute which microphone you are using.
- The microphones max volume is 89%; please adjust using the + / - buttons.



Reminders/Notes:

- By touching the Crestron unit, you are turning on the projector
- If the projector does not turn on, press the projector icon button on right of the blue circle from the image above.
- The “projector button” will either turn on or off the projector. Please give it a few minutes once pressed for the projector to load up or to shut down
- User may need to adjust PC setting to use the room speakers

AFTER USER IS FINISHED, PLEASE SHUTDOWN SYSTEM